























13	40	43	44	57	62	71	87	89	93
				 3,5x12					
x8	x2	x4	x4	x4	x2	x6	x6	x1	x1

Skuffe 31 30/40 222 Vejledning nr. 42



(13)	(40)	(43)	(44)	(57)	(62)	(71)	(87)	(89)	(93)
				 3,5x12					
x8	x2	x4	x4	x4	x2	x6	x6	x1	x1

Skuffe 31 30/40 222 Vejledning nr. 42

